



NL Lock Backup Key Instructions



Using the Backup Key

A "Backup Key" has been provided in case you have forgotten or lost your security code. To open the safe using the backup key, follow the steps below:



1. Remove the keypad by sliding the keypad assembly up towards the top of the safe until it is released. (Fig. 1)
2. Insert the backup key into the key hole and turn clockwise 1/4 turn (until stopped). While holding the key in the unlock position (Fig. 2) rotate the handle and open the door.
3. WITH THE DOOR OPEN, remove the backup key and reattach the keypad, aligning the two screws at the front face of the door with the two plastic holes on the rear of the keypad, slide the assembly down towards the floor to lock in place.

KEEP THE DOOR OPEN UNTIL YOU HAVE ENTERED AND TESTED YOUR NEW SECURITY CODE

1. Enter your new security code following the instructions provided in the Cannon Safe manual.



(Fig. 1)



(Fig. 2)